





MØBLER

- A PHILOSOPHY -



G30, Sengeramme

Samlevejledning


**MÖBLER**

- A PHILOSOPHY -


Indhold



A x 12




B x 16




C x 4



D x 36




E x 2




F x 8




G x 2




H x 1




I x 1




J x 1




K x 1



L x 1



M x 1




N x 2




O x 1



P x 1



Q x 2




R x 1



S x 1


For sikker og korrekt samling, er det nødvendigt at være to mennesker. Det kan være nødvendigt at efterspænde maskinskruer efter et stykke tid, derfor bedes du gemme værktøjet (G).

1




Beslut hvilken af de to højdeindstillinger møblet skal have - 11 cm/Høj eller 17 cm/Lav. Samlevejledningen tager udgangspunkt i den høje indstilling, vær derfor opmærksom på dette undervejs hvis lav indstilling ønskes.


2



3



4




! Det er muligt at montere hovedgærdet ved to højdeindstillinger også. I eksemplet tages der udgangspunkt i den høje. Ønskes hovedgærdet med den lave indstilling, vendes dette 180 grader i den lodrette retning.




MÖBLER

- A PHILOSOPHY -

5



6







MÖBLER

- A PHILOSOPHY -

7



8







MØBLER

- A PHILOSOPHY -

9



10







MÖBLER

- A PHILOSOPHY -


11



12




13



Er høj instilling på sengen valgt, vær da opmærksom på at både (P) og (O) skal bruges som det støttende ben i midten og derfor sættes de sammen. Ønskes lav, kan man nøjes med at bruge (P).



14





MÖBLER

- A PHILOSOPHY -



G30, Bed Frame

Assembly Instructions




MÖBLER

- A PHILOSOPHY -


Content



A x 12




B x 16




C x 4



D x 36




E x 2




F x 8




G x 2




H x 1




I x 1




J x 1




K x 1



L x 1



M x 1




N x 2




O x 1



P x 1



Q x 2



R x 1



S x 1


To ensure safe and correct assembly, it is necessary to be two people.
It may be necessary to retighten nuts after a while, therefore please save the tool (G).



MÖBLER


- A PHILOSOPHY -

1



Decide which of the two height settings the bed should have - 11 cm/High or 17 cm/Low. The assembly instructions are based on the high setting, so be aware of this along the way, if you want the low setting.

2







MÖBLER

- A PHILOSOPHY -

3



4




! It is possible to mount the headboard at two height settings as well. The example is based on the high setting. If you want the headboard with the low setting, turn it 180 degrees in the vertical direction.




MÖBLER

- A PHILOSOPHY -

5



6







MÖBLER

- A PHILOSOPHY -

7



8







MÖBLER

- A PHILOSOPHY -

9



10







MÖBLER

- A PHILOSOPHY -

11



12






MÖBLER

- A PHILOSOPHY -

13



! If high setting on the bed is chosen, please note that both (P) and (O) should be used as the support leg in the centre and therefore joined together. If you want low setting, you can just use (P).

14

